

TRAVEL WITH PEACE OF MIND,
PROTECT YOUR VEHICLE WITH

UNITED STATES
WARRANTY CORPORATION

COMPONENT	AVERAGE REPAIR
ENGINE	\$4,700 - \$48,000
AUTOMATIC TRANSMISSION	\$2,200 - \$10,800
AIR CONDITIONER	\$500 - \$2,000
RADIATOR	\$850 - \$6,000
FUEL PUMP	\$800 - \$5,000
GENERATOR	\$500 - \$5,000
ALTERNATOR	\$500 - \$1,500
INVERTER	\$500 - \$2,900
WATER HEATER	\$250 - \$1,500
REFRIGERATOR	\$450 - \$2,200
POWER JACK	\$275 - \$2,100
SLIDE OUT	\$250 - \$3,300

BENEFITS

SENIOR CITIZEN/MILITARY ADVANTAGE:

25% reduction of your deductible for each.

DEDUCTIBLE REDUCTION:

A 50% reduction of your deductible for repairs being performed at the dealer/seller.

MANUFACTURER'S DEDUCTIBLE:

Up to \$100 towards your manufacturer's deductible for repairs that would otherwise be covered under our Service Contract.

PET BENEFIT:

Up to \$300 for pet assistance.

WINTERIZATION BENEFIT:

Up to \$125 for winterization services.

FOOD SPOilage:

Up to \$150 for food spoilage.

EMERGENCY SERVICE CALLS:

\$125 for an on-site service call if breakdown renders the vehicle immobile.

ROADSIDE ASSISTANCE/FLUID/LOCKOUT:

\$500 for battery jump, flat tire, fluid delivery and lockout.

TOWING:

\$1,000 for towing.

TRIP INTERRUPTION:

\$150 per day for meals/lodging expenses.

SUBSTITUTE TRANSPORTATION:

Up to \$500 for a rental vehicle.

WHY CHOOSE UNITED STATES WARRANTY CORPORATION?

45+ YEARS IN BUSINESS


- Highly experienced, professional staff
- Questions & requests are handled in a timely manner

COMPETITIVE COVERAGE

- 4 different plans with competitive pricing to fit your needs
- Policies often pay for themselves in just one or two claims
- Selling your vehicle? Your contract is cancellable and transferable

WE CARE ABOUT OUR CUSTOMERS

- Claims adjusters are available 24/7
- Service approved at any repair facility in the U.S. or Canada
- 60-day money back guarantee



SERVICE, INTEGRITY AND TRUST SINCE 1975

United States Warranty Corporation

6150 PARKLAND BLVD, SUITE 200
MAYFIELD HEIGHTS, OH 44124

PHONE: (800) 233-9878
FAX: (440) 516-2604
RVSALES@USWCEAGLE.COM

WWW.USWCEAGLE.COM

Not affiliated with United States Warranty Corp. of Florida.



United States Warranty
CORPORATION
SERVICE, INTEGRITY AND TRUST SINCE 1975



RECREATIONAL VEHICLE DIVISION

MOTORHOMES
CONVERSION VANS



RVSALES@USWCEAGLE.COM

PLAN: EAGLE

- 1. ENGINE COMPONENTS:** Gasoline Engine: all internally lubricated engine parts and the cylinder heads, engine block, intake manifold, oil pan, timing cover and the valve covers. External Engine Parts: dipstick, dipstick tube, engine cushions, engine mounts, engine water pump, flywheel/flexplate, flywheel ring gear, harmonic balancers and the harmonic balancer pulley. Exhaust manifolds are covered on new vehicles only. Diesel Engine Parts: all of the above parts and the: cylinder sleeves/liners, fuel injectors, mechanical injection pump, turbocharger and the wastegate actuator.
- 2. AUTOMATIC TRANSMISSION COMPONENTS:** all internally lubricated automatic transmission parts, the oil pan and the transmission case. External Automatic Transmission Parts: dipstick, oil fill tube, oil cooler, oil cooler lines and the transmission mounts. 4X4 Transfer Unit Parts: all internally lubricated parts within the transfer case.
- 3. DRIVE AXLE COMPONENTS:** all internally lubricated drive axle parts and the drive axle housing. External Drive Axle Parts: constant velocity joints, drive shaft, drive shaft support, drive wheel hubs and the half shafts.
- 4. ELECTRONIC HI-TECH COMPONENTS:** camshaft position sensor, coolant temperature sensor, crank position sensor, electronic anti-detonation controller, electronic anti-detonation sensors, electronic driver information display, electronic driver information display module, engine electronic control module, engine temperature sending unit, fuel injection control module, intake air temperature sensor, head temperature sensor, knock sensor, manifold absolute pressure sensor, mass air flow sensor, phase sensor, throttle position sensor, transmission temperature sensor, vane air flow sensor and the vehicle speed sensors.
- 5. AIR CONDITIONING/VENTILATION COMPONENTS (dash):** 12 volt vacuum pump, air duct outlets, air ducts, accumulator, blower motor, blower motor fan, condenser, condenser fan motor, evaporator, expansion valve, heater control valve, heater core, high/low cut off switches, idler bearings, orifice tube, power module, pressure cycling switch, programmable temperature control, receiver drier, Schrader valve and the suction valve. Auxiliary Heating System: auxiliary blower motor and the auxiliary heater core. Compressor: clutch, coil, compressor and the switch.
- 6. BRAKE COMPONENTS:** backing plates, booster pump, combination valves, disc brake calipers, equalizer valve, fittings, hydraulic control unit, hydro boost, hydrovac, master cylinder, power brake booster, power brake cylinder, rear actuators, self adjusters, steel hydraulic brake lines, wheel cylinders and the vacuum assist booster. Air Brakes: air brake compressor, auto bleeder valve, compensating valve, diaphragm, governor, slack adjusters, tank and the treadle. Anti-lock Brakes: anti-lock brake pump, electronic anti-lock brake actuator, electronic anti-lock brake computer and the wheel speed sensors. Parking Brake: cables and the linkage.
- 7. ELECTRICAL COMPONENTS:** air horn compressor, alternator, battery disconnect switch, battery isolator, brake light switch, clockspring, coils, distributor, dual battery paralleling switch, engine temperature gauge, fuel gauge, hand operated driver control switches, horn, horn switch, ignition switch, ignition switch cylinder, odometer, oil pressure gauge, oil pressure sending unit, power driver seat motor, radio antenna motor, relays, solenoids, speedometer, starter, tachometer, transmission temperature gauge, turn signal switch, voltage regulator, volt gauge, window defroster, window wiper motor and the windshield washer pump. Back Up

- Alarm: audible device and the switch. Cruise Control: engagement switch, servo and the transducer. Power Door Locks: actuators and the control switches. Power Mirrors: control switches and the motors. Power Windows: control switches, motors and the regulators.
- 8. ENGINE COOLING COMPONENTS:** anti-freeze filled radiator, coolant recovery tank, cooling fan clutch, cooling fan controller module, cooling fan motor and the electric block heater. The intercooler/charge air cooler are covered on new vehicles only.
- 9. FUEL SYSTEM COMPONENTS:** Diesel Parts: fuel heater, fuel tank, fuel transfer pump, metal fittings, metal fuel lines and the sending unit. Gasoline Parts: auxiliary tank switch, fuel injectors, fuel pressure regulator, fuel pressure tap, fuel tank, fuel pump, metal fittings, metal fuel lines and the sending unit.
- 10. STEERING COMPONENTS:** bearings, bell crank, center link, control valve, control cylinder, cooler, cooler lines, drag link, gear box, hydraulic control unit, idler arm, intermediate shaft, main shaft, pitman arm, power steering cylinder, power steering pump, rack and pinion gear, steering column, steering damper, steering knuckles, tie rod ends and the wheel hubs.
- 11. SUSPENSION COMPONENTS:** air suspension compressor, air suspension compressor lines, ball joints, coil springs, control arm shafts, king pins, leaf springs, lower control arms, ride height sensors/valves, stabilizer shaft links, strut bar, strut links, strut rods, struts, suspension air bags, torsion bars, upper control arms and the wheel bearings.
- 12. TAG AXLE COMPONENTS:** axle, axle bearings, axle housing and the axle spindles.
- 13. AIR CONDITIONING/HEAT PUMP/VENTILATION COMPONENTS:** accumulator, blower motor, blower motor fan, blower motor wheel, ceiling vent fans, compressor, condenser, ducts, duct work, electronic module, evaporator, expansion valve, heat strips, high/low cut off switches, pressure cycling switch, printed circuit board, receiver drier, relays, reversing valve, run capacitors, Schrader valve, start capacitors and the thermostat.
- 14. AUXILIARY GENERATOR COMPONENTS:** Gasoline/L.P. Parts: all internally lubricated engine parts and the cylinder heads, engine block and the valve covers. Diesel Parts: same as Gasoline/L.P. Auxiliary Generator Parts plus the mechanical fuel injection pump, radiator and the water pump. Electrical Parts: alternator, coach inverter, coach inverter control panel, electric fuel pump, gauges, hour meter, inverter controller, manually operated switches, power converter, printed circuit board, rotor, starter, starter solenoid, stator, transfer switch and the voltage regulator.
- 15. ELECTRIC STEP COMPONENTS:** controller, gear, linkage, motor, printed circuit board and the switches.
- 16. L.P. SYSTEM COMPONENTS:** automatic shut off, detectors, fittings, gauges, L.P. lines, L.P. tanks, pigtails, regulators and the valves.
- 17. NON-HYDRONIC L.P. AND ELECTRIC FURNACE COMPONENTS:** blower motor, blower motor fan, blower motor wheel, burner assembly, ducts, duct work, fittings, gas valve, igniter, limit switch, printed circuit board, sail switch, thermocouple and the thermostat.
- 18. NON-HYDRONIC L.P. AND ELECTRIC WATER HEATER COMPONENTS:** burner assembly, control panel, control switches, fittings, gas valve, heating element, igniter, pressure relief valve, printed circuit board, tank, thermocouple and the thermostat.
- 19. RANGE/OVEN COMPONENTS:** burner assembly, burner valves, fittings, heating element, igniter, induction cooktop, microwave convection oven, microwave oven, power hood fan, power hood fan motor, power hood fan switch, printed circuit board, thermocouple and the thermostat.

- 20. REFRIGERATOR COMPONENTS:** burner assembly, compressor, condenser, cooling unit, evaporator, expansion valve, fan, fittings, heating element, igniter, printed circuit board, thermocouple and the thermostat.
- 21. WASTE SYSTEM COMPONENTS:** ball valves, fittings, gate valves, holding tanks, holding tank flush valves, interior drain lines, macerator pump, non-powered slide valves, non-powered toilet, traps and the water inlet valves.
- 22. WATER SYSTEM COMPONENTS:** ball valves, check valves, fittings, gate valves, holding tanks, interior supply lines, shower faucet, shower head, sink faucets, traps, water inlet valves, water manifold and the water pump.
- 23. SEALS & GASKETS COMPONENTS:** seals & gaskets on parts which prevent the loss of fluids or refrigerants. Fluid seals must be leaking to an active drip.
- 24. AUDIO/VIDEO COMPONENTS (Factory or Dealer Installed Only):** AM/FM/satellite stereo, CB radio, component CD/DVD player, driver observation cameras, driver observation monitors, LCD televisions/monitors (up to 65") and the manual crank over-the-air TV antenna.
- 25. DELUXE APPLIANCE COMPONENTS:** blender, carbon monoxide detector, central vacuum cleaning system, clothes dryer, clothes washer, dishwasher, external barbecue, food processor, freezer, ice maker, in-sink disposal, smoke detector and the trash compactor. Over the Door, Patio and Window Awnings: anemometer, cam lock, crank mechanism, motor, printed circuit board and the torsion springs.
- 26. ELECTRIC LIFT BED COMPONENTS:** bearings, control panel, control switches, drive gears, drive shaft, electric motor, lift chains, limit switch, printed circuit board and the tracks.
- 27. HYDRONIC FURNACE COMPONENTS:** air accumulator, compressor, control box, fan motor, fan motor bearings, fuel pressure regulator, fuel pump, heat exchanger, heating element, hour meter, igniter, L.P. solenoid, L.P. valve, main control switch, printed circuit board, tempering valve, thermostat and the water pump.
- 28. JAKE BRAKE/EXHAUST BRAKE COMPONENTS:** butterfly plate, control valve, housing, linkage, main control switch, master piston, slave piston, solenoid and the throttle control switch.
- 29. LEVELING SYSTEM COMPONENTS (electric/hydraulic/pneumatic):** actuators, air leveling compressor, air leveling compressor lines, control box, control switches, cylinders, electric motor, electric switch, electric switch wiring harness, fittings, gear box, gears, hydraulic lines, leveling air bags, printed circuit board, pump, reservoir, sensors, solenoid valves and the worm gears.
- 30. SLIDE OUT ROOMS/RAISED ROOF COMPONENTS (electric/hydraulic):** actuators, control box, control switches, cylinders, drive cables, electric motor, electric switch, electric switch wiring harness, fittings, gear box, gears, hydraulic lines, printed circuit board, pump, rams, reservoir, rollers, sensors, solenoid valves, topper awning springs, tracks and the worm gears.
- 31. ULTRA ELECTRONIC HI-TECH/ENHANCED ELECTRICAL COMPONENTS:** LED lighting, light fixtures, light switches, solar panel charge controller, solar panels and the spot lights. Electronic Entrance: actuators, printed circuit board, servos, solenoids, touchpad and the transmitter. Electric Toilet: controller, electric slide valves, flush control switch, printed circuit board, pump motor, vacuum pump, water

- solenoid valve and the wiring harness. Global positioning system and the thermometer.
- 32. WEAR AND TEAR COMPONENTS (Engine, Steering, Suspension and Transmission Components):** Wear and Tear breakdown will be deemed to have occurred when a covered part has worn beyond the manufacturer's tolerances allowed for the particular part.
- 33. WHEEL CHAIR LIFT COMPONENTS/ADA PACKAGE:** actuators, electric/hydraulic motor, hydraulic pump, locking handrails, manual hand pump, power control switch, pressure release valve, relays and the steel frame.
- 34. SATELLITE SYSTEM COMPONENTS (Factory or Dealer Installed Only):** all parts of the satellite system except wiring.
- 35. HEATED FLOOR COMPONENTS:** electric heating elements, sensors, thermostat, transformers and the wiring.
- PLAN: EAGLE PLUS**
- The plan includes coverage numbers #'s 1-23 and options #'s 24-35 contained in Plan: Eagle Motorized. Only listed parts are covered.
- Please note:** option #36 Consequential Damage, option #37 Enhanced Wheel & Tire and option #38 Enhanced Service Calls are not included in Plan: Eagle Plus Motorized and must be purchased separately.
- PLAN: EAGLE GUARDIAN**
- This plan is our exclusionary coverage. Plan: Eagle Guardian Motorized provides coverage for virtually all factory approved and factory or dealer installed electrical, electronic, hydraulic and/or mechanical parts essential to the operation of your vehicle. **Please note:** option #36 Consequential Damage, option #37 Enhanced Wheel & Tire and option #38 Enhanced Service Calls are not included in Plan: Eagle Guardian Motorized and must be purchased separately.
- OPTIONAL COVERAGE FOR PLAN: EAGLE PLUS & PLAN: EAGLE GUARDIAN**
- 36. CONSEQUENTIAL DAMAGE:** coverage for the following parts if damaged due to an authorized breakdown: batteries, belts, exhaust and emission systems, filters, fuses, glass lenses, hoses, light bulbs, safety restraint systems, sealed beams, spark plugs, spark plug wires, intelligent cruise control systems and the wiper blades.
- 37. ENHANCED WHEEL & TIRE (New Vehicles Only):** provides coverage for damages to your vehicle's wheels and/or tires caused by a road hazard while travelling on a public roadway. Road hazards are defined as glass, nails or potholes and other objects or conditions which should otherwise not exist that puncture or damage a tire. Minimum tread depth required to qualify for coverage under this optional provision is 1/16th of an inch.
- 38. ENHANCED SERVICE CALLS:** in the event of an authorized breakdown, we will reimburse you for actual expenses up to \$250.00 (in addition to the repair costs) for an on-site service call performed by a licensed service provider. (not included in Plan: Eagle, Plan: Eagle Plus or Plan: Eagle Guardian, unless this option is purchased. Cannot be combined with the Emergency Service Calls benefit.)

PLAN: EAGLE INFINITY

This timeless plan delivers to you the coverage provided by Plan: Eagle Guardian Motorized. Further, this plan has no expiration date and no expiration mileage. Also included in Plan: Eagle Infinity Motorized are option #36 Consequential Damage, option #37 Enhanced Wheel & Tire and option #38 Enhanced Service Calls. **Please note:** all repair costs in total during the term of this contract is the fair market value of the vehicle immediately prior to the breakdown.



This brochure is for promotional purposes only; it is not a contract. Ask your authorized USWC dealer for a complete copy of the actual service contract.